

UFO UV LAMP – HT1

– MANUAL GUIDE –

PLEASE READ ALL THE SAFETY INSTRUCTIONS BEFORE THE DEVICE OPERATION.

KEEP THE MANUAL GUIDE SAFE FOR FUTURE REFERENCE.

PRODUCT INTRODUCTION

The UFO UV Lamp – HT1 is a new, developed version of the popular UFO UV Lamp. The UFO UV Lamp – HT1 got new plastic setting UV bulbs (2pcs), stronger power cord holder, special "START" Start/Stop switcher and a 3min (180sec) Timer for the more professional work. The UFO UV Lamp expected reliable capacity and work bearing is not changed at all. The UFO UV Lamp – HT1 is used for the UV- and LEDUV light curing artificial nail substances consolidation.

Specification:	OPERATION
UFO UV LAMP – HT1	ATTENTION! Before the machine operation, check the device and its cable just state.
Input: 220-240V ; 50Hz	[1.] Unpack the device from the packaging.
Power: 18W±10%	[2.] Choose a suitable, stable place for the device usage.
Amperage: 1.0A	[3.] After the device setting, connect the power cord to the outlet.
Weight: 975g	[4.] Select the desired operation time with the switcher at the back of the device. 1.) Timer (I): 3min (180sec) or 2.) Continuous (II): Endless usage. ATTENTION: in the end of the Timer operation, the device will automatically turn off without sound indication.
Measure: 240*210*132mm	[5.] For the device operation, press the „START“ Start/Stop button at the top of the device. The operation will not start until the “START” Start/Stop button is not pressed. To Stop/Start the device during in use press the „START“ Start/Stop button. The Timer will be run from the start.
Timer: 3min (180sec)	[6.] For the Time change during in use, set the switcher on the back of the device in „O“ (Off) position than select the desired operation time and press the „START“ Start/Stop button. The Timer will be run from the start.
UV classification: UV Type 3 (365nm)	[7.] After the work is finished with the device, turn it off with the switcher on the back. Set the switcher on the „O“ (Off) position, than pull out the power cord from the outlet
Accessories: 2pcs UV bulb (9W, 365nm, plastic socket type)	

ATTENTION! Pay attention NOT to touch the device light bulbs with anything during in operation [e.g.: skin, nails or other professional accessories/items or materials]. As well as do not let any irrelevant object thought the device openings, joints or sockets.

Notice:

If the substance causes any burning sensation on the fingernails during use (it depends on the used substances and the sensitivity of the fingernail), press the finger pad below and the other fingers put the fingernails in front of the machine and set them in diffuse light for 20-30 seconds. After that, insert the whole hand into the machine. Use the machine periodically, turn it off for 5-10 minutes after 30-45 minutes of use.

CLEANING/MAINTENANCE

ATTENTION! DO NOT disassemble the device! Before the cleaning/maintenance always anneal the device (turn off the machine, than remove the power cord from the AC outlet), as well as wait for the device- and the light bulbs full cool down! It is recommended to wear gloves during in the procedure.

For the UFO UV Lamp – HT1 cleaning/maintenance use compressed air, brush and a non-synthetic soft cloth.

Put the device into a stable, even surfaced place (it is recommended to put a cloth under the device), than wipe out the device external- and inner panel with the non-synthetic dry, soft cloth. Turn the device upside down than, remove the UV bulbs (see **UV BULB CHANGE** chapter). Clean the inner panel and UV bulbs setting with brush and compressed air. Place back the UV bulbs (see **UV BULB CHANGE** chapter), than turn back the device to its original position. Clean the hard to reach parts (switchers, joints, settings) with brush and compressed air. For the last step, wipe out the machine external panel with the dry, soft cloth.

NOTICE: If it necessary the device external panel can be cleaned with a lightly moist, soft cloth, but pay attention that the device CANNOT have any liquid inside in it or in its switchers, openings or sockets, as well as CANNOT be contacted with the device power cord! After the moist cleaning, always wait for the device full dry as well as do not put it under it charge at least 1-2 min.! DO NOT use solvent detergents!

In case of average frequency use, clean the device and its parts according to the described above at least once a week.

For future information about the device cleaning/maintenance visit our website: <http://www.nails.tv> or if it requires look for the place of purchase.

UV BULB CHANGE and STORAGE

ATTENTION! DO NOT disassemble the device! Before the UV bulb change always anneal the device (turn off the machine, than remove the power cord from the AC outlet), as well as wait for the device- and the bulbs full cool down! It is recommended to wear gloves during in the bulb change procedure.

UV BULB CHANGE: Put the device into a stable, even surfaced place (it is recommended to put a cloth under the device), than turn the device upside down. Pull out the used UV bulbs with a careful certain move, than clean the bulb settings and the surrounding area with brush and compressed air. Place into the new bulbs until they click. If the UV bulbs placed in correctly, they cannot be loose or wobble in their places. Pay attention to use only original and right type of plastic socket UV bulbs (UV-9W-L 365nm) in the device. Turn back the device to its original position and check the device and the bulbs proper operation.

ATTENTION! The device can only be operated with plastic socket bulbs.

If you notice lower efficacy during in use check the UV bulbs proper functioning and if it reasonable, replace them according to the described above (see **UV BULB CHANGE**).

In the case of the device is not operate properly after the UV bulb change, check the UV bulbs correct placing (see **UV BULB CHANGE**) and the correct type (UV-9W-L 365nm). If the problem is still standing, take the device into the place of purchase and ask for professional help.

If the UV bulb change causes difficulty, than take the device to the place of purchase and ask for professional help.

In case of average frequency use, check the UV bulbs proper functioning at least once a month and if it is reasonable, replace them according to the described above (see **UV BULB CHANGE).**

STORAGE: Store the device and its parts always in a dry place, far from radiant heat in a clean state. Wind the power cord loosely together, pay attention no to break it.

Before the device installation always check the device and its power cord just state.

SAFETY CAUTIONS

- [1.] Only for indoor use, between 0~40°C (32~104°F)!
- [2.] The machine cannot be left behind without supervision when it is turned on.
- [3.] Do not put the machine onto places where it can be knocked down, or may fall off. Use/store the device only in stable, even surfaced places!
- [4.] The machine CANNOT have any liquid inside in it or in its switchers, openings or joints, as well as CANNOT be contacted with the device power cord.
- [5.] Do not ever touch the machine or its power cord with moist/wet hand!
- [6.] DO NOT ever activate the machine if its power cord or socket is damaged, as well as if it had any kind of damage or fell into the water! Take the device to the place of purchase for examination and repair. Only authorized persons can repair the device!
- [7.] Use/store the device only in dry places and keep it far from radiant heat! Avoid damp, wet places!
- [8.] Do not let any irrelevant objects thought the device openings, joints or sockets.
- [9.] Do not touch the device light bulbs with anything during in operation (skin, nails or other professional accessories/items or materials).
- [10.] DO NOT ever look directly into the device light source during in operation, as well as DO NOT let the skin to be exposed excessive amount UV radiation.
- [11.] The device can only be operated with plastic socket bulbs!
- [12.] The electric parts of the machine may have electric charges on them even when the device is turned off. At the end of the device use, always anneal the machine (turn off the device, than remove the power cord from the AC outlet).

For more information about the device, visit our website: <http://www.crystalnails.com> or look for the place of purchase.

NOTICE!

If any case of malfunction was found or any parts of the device has to be replaced/repared, please look for the place of purchase.

Importer: Elite Cosmetix LTD.; Jozsef Krt. 44., H-1085 Budapest, Hungary